Dell Latitude D610 Battery Replacement

Replacement of the battery for a Dell Latitude D610

Written By: Cinthya




INTRODUCTION

Replacing a defective battery is pretty easy and will increase the time your computer will last after charging.

TOOLS:

- Phillips #1 Screwdriver (1)

Step 1 — Battery





- Remove the 3.9 mm Phillips #1 screw from the battery compartment.

Step 2








- Locate the laptop battery release button lock
- Push the battery release in the direction of the arrow, and pull upward.

Step 3



- Remove the battery from its compartment.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 01:20:08 PM.